

COMPLETE RESOURCE GUIDE FOR

HUMANE STUNNING













OUR COMMITMENT TO HUMANE STUNNING



Bunzl Processor Division has established itself as the premier partner for humane handling in the food processing industry. Our commitment to this cause is unparalleled in the marketplace. We offer FREE ON-SITE CONSULTATION to assist customers in determining the right humane stunning equipment needs for each environment.



Chuck Bildstein Humane Stunning and Equipment Specialist

Chuck Bildstein, has been recognized as one of the top influences in Humane Animal Handling. He has worked closely with Temple Grandin, Ph.D., in the area of humane stunning and was part of the AMI team that traveled to Washington DC to present at a congressional briefing on animal welfare, and has lectured at various universities in the U.S. and Canada.

Bildstein is leading our efforts by working alongside many of our customers in their plants to significantly improve the welfare of their animals. Bildstein understands how critical equipment and training is to animal welfare and he takes pride in helping plants work through concerns and issues. In addition to helping processing plants, Bildstein also assists with on-farm euthanasia. BPD's equipment is extremely portable, proving it to be ideal for applications on the farm for producers as well as for veterinarians.

In addition, BPD has gone the extra mile by developing safety, maintenance and training videos which are available for FREE to help our customers learn proper procedures to keep workers safe on the job, and keep their stunning equipment running at the utmost efficiency.

ORDERING FROM US IS EASY:



Phone Orders 800-456-5624

- Monday Friday, 7:00 am 5:30 pm CST.
- Knowledgeable sales staff.



Fax Orders 800-329-5624

- Order 24 hours a day, 7 days a week.
- Easy to use.



Online Orders www.bunzlpd.com

- Order 24 hours a day, 7 days a week.
- Easy to use.
- Secure.



Email Orders kochsupplies@bunzlusa.com

- Order anytime.
- Easy to use.

NEED ASSISTANCE?

Call 800-456-5624 and we'll be happy to help you.

TERMS AND CONDITIONS

For full Terms & Conditions information, visit our website www.bunzlpd.com

Prices

Any prices in this catalog are current prices at publication and are subject to change without notice. In the rare event of a printing error, we reserve the right to charge the correct price. Confirm current prices and availability by phone, fax, or e-mail. Prices are in U.S. dollars and do not include applicable taxes. Current up-to-date pricing can be found on our website www.bunzlpd.com.

Payment Terms



We accept Visa®, MasterCard®, American Express®, Discover® and checks by phone (via TeleCheck®).

We offer credit terms of Net 10 days for customers with a minimum monthly volume of \$500, subject to credit approval.

Symbol Legend



This symbol highlights an item that is made in the USA.



These products are considered hazardous materials, and therefore could require special shipping. Call for details.



Certain items in this catalog are not returnable and have a **'No Return'** symbol next to them.

Satisfaction Guarantee

When purchasing from our catalog, you can rest assured that any product you order will meet your expectations – guaranteed! That's a promise from our friendly and knowledgeable Customer Service Representatives. However, in the rare case that any stocked supply item fails to meet with your expectations or approval, simply call our toll free number within 30 days and we can arrange for a repair, refund, exchange or credit towards your next purchase, except for those items noted as "No Return" items.

Call for warranty information on non-stock or special order items (i.e. equipment, doors, walls, etc.).

A restocking or repair fee may apply on certain special order items.

Returns

Please call our Customer Service
Department for details and to obtain
a return authorization number
before returning items.

Shipping

Unless specified, we will determine the most expedient and efficient means of shipment based on dimensional weight - UPS or LTL (less than truckload). Alternate delivery may require additional cost. Appropriate charges will be added to your invoice. Additional Terms & Conditions apply.

HUMANE STUNNING

VISIT WWW.BUNZLPD.COM

FOR ADDITIONAL JARVIS®
PROCESSING SUPPLIES & EQUIPMENT

MEAT CUTTING
BONING MACHINERY
BAND SAWS
SLAUGHTER EQUIPMENT
CARCASS OPENING
SPLITTING SAWS
HOCK CUTTERS
SKINNING MACHINES

NEED CASH SPECIAL OR MAGNUM STUNNER REPLACEMENT PARTS? Call 800-456-5624 for ordering assistance

TABLE OF CONTENTS

| | About Us |
|---|--|
| | Power Actuated Stunner Chart |
| | JARVIS® PAS-PS 22R Type-P Standard .22 Cal |
| | JARVIS® PAS-PS 25S Type-P Standard .25 Cal 6- |
| | JARVIS® PAS-PHDS 25R Type-P Heavy Duty .25 Cal 8- |
| | JARVIS® PAS-PHDL 25R Type-P Heavy Duty, Long Bolt10-1 |
| ◩ | JARVIS® PAS-PCN 25R Type-P Concussion |
| | JARVIS® PAS-P Veterinary Kit |
| Е | JARVIS® PAS-CCN 22R Type-C Concussion |
| G | JARVIS® PAS-CS 25S Type-C Standard .25 Cal 18-1 |
| | JARVIS® PAS-CL 25S Type-C Long Bolt .25 Cal20-2 |
| | JARVIS® PAS-CSHD 25S Type-C Super Heavy Duty 22-2 |
| | JARVIS® PAS-C RB 25R Type-C Retracting Bolt, .25 Cal24-2 |
| | JARVIS® PAS-C IF 25S Type-C Handheld, Impact Fire 26-2 |
| | JARVIS® PAS-CLH IF 25SType-C Long Handle, Impact Fire . 26-2 |
| | JARVIS® PAS Stun Tester |
| | PAS Stun Check Instructions & Safety Procedures |
| | JARVIS® PAS Power Load Cartridge Chart |
| | PAS Safety Messages & Procedures |
| | PAS Type-P Safety & Maintenance Instructions |
| | PAS Type-C Safety & Maintenance Instructions |
| | PAS Type-C Concussion Safety & Maintenance Instructions 3 |
| | PAS Type-C Impact Fire Safety & Maintenance Instructions 3 |
| | JARVIS® USSS-1 Pneumatic Stunner |
| | JARVIS® USSS-2A, Non-Penetrating Pneumatic Stunner |
| | JARVIS® USSS-1/2 Half-Size Pneumatic Stunner |
| | JARVIS® Pneumatic Stunner Tester |
| À | Body Protection |
| | Cleaning Tools |
| F | Safety & Protection Products |
| ŀ | For more information |





READY TO UPGRADE YOUR CAPTIVE BOLT TOOLS?

We offer trade-in credit. Call 800-456-5624 for more information

Bunzl Processor Division has transitioned to the Jarvis Products Corporation line of captive bolt equipment. We are proud to be able to offer this line of equipment to your company because of the added value to you – our customer. Some of these advantages:

MADE IN THE USA

All of the Jarvis® stunners, replacement parts & power loads are made in USA! Jarvis® is the first manufacturer of handheld, cartridge-fired captive bolt tools in the United States. The equipment is manufactured in Middletown, CT. By adding this new line of equipment, Jarvis® has been able to hire an additional 13 US employees with plans to hire more as the business increases worldwide. In addition, Jarvis has invested in several CNC machines to manufacture the parts necessary for this line.

SERVICE

We have 26 service professionals to assist in the maintenance of Jarvis® equipment. These service professionals, combined with Chuck Bildstein's technical expertise, will provide personalized service to your company that no other supplier can provide. In addition, we have a service technician on-location in the Bunzl Processor Division warehouse in Kansas City, MO with 23 years of experience repairing captive bolt tools.

SUPPORT

As always, on-site support and training are provided at no charge. This is an ongoing offer during the life of the equipment. This training includes expert support on safety, cleaning & maintenance of all equipment and supplies purchased. All Jarvis equipment sold comes with a ONE YEAR WARRANTY. The manufacturer's response time to customer needs is second to none in the industry.

COMPATIBILITY

Jarvis Products Corporation manufactures replacement parts that will work interchangeably with your Accles & Shelvoke tools. Give us a call to find the Jarvis® parts that will work seamlessly with your Cash Special or Magnum tools.

AVAILABILITY

Bunzl Processor Division inventories Jarvis® tools, replacement parts and power load cartridges in several warehouses located throughout the US. A majority of these items are located in Kansas City, MO and Omaha, NE. The lead time for these items is very short – in most cases it is a few days to replenish our inventory versus several weeks delivery from competitors.





Jarvis Products Corporation is the world's largest manufacturer of meat and poultry processing equipment. For 115 years, the Jarvis name has stood for quality, craftsmanship, dependability and ruggedness under difficult field conditions. Jarvis specializes in captive bolt stunners, band saws, slaughter equipment, carcass opening and splitting saws, hock cutters, automatic and

robotic splitting machines, and skinning machines. It also supplies auxiliary equipment such as vacuum pumps, balancers, and a full line of hydraulic power units. Headquartered in a state-of-the-art 175,000 square-foot manufacturing facility, Jarvis employs 200 skilled craftsmen in Middletown, Connecticut, U.S.A. The Jarvis product line is sold and serviced worldwide through 19 subsidiaries on 6 continents as well as Jarvis' J26 Federation of distributors.

POWER ACTUATED STUNNERS (PAS) Comparison Chart

| MODEL | YPE-P (Pistol Style) CALIBER / DESCRIPTION | APPLICATIONS | SEE PAGES |
|--------------|--|-----------------------------|--------------|
| PAS-PS 22R | .22 Caliber Standard Bolt | にしててこれ | 4-5 |
| PAS-PS 25S | .25 Caliber Standard Bolt | になるとと | 6-7 |
| PAS-PHDS 25R | .25 Caliber, Heavy Duty Standard Bolt | として | 8-9 |
| PAS-PHDL 25R | .25 Caliber, Heavy Duty Long Bolt | | 10-11 |
| PAS-PCN 25R | .25 Caliber, Heavy Duty Concussion Head | → ∀ № ₹ < 50 lbs. | 12-13 |
| PAS-PS 25R | .25 Caliber, Heavy Duty Veterinary Kit | なとはにして | 14-15 |

| | TVDE C (Cylindor Sty | lo] | |
|----------------|--|------------------|--------------|
| MODEL | TYPE-C (Cylinder Sty CALIBER / DESCRIPTION | APPLICATIONS | SEE PAGES |
| PAS-CCN 22R | .22 Caliber, Poultry Tool Concussion Head | 2 ¥ € € <50 lbs. | 16-17 |
| PAS-CS 25S | .25 Caliber, Standard Bolt | はまずま | 18-19 |
| PAS-CL 25S | .25 Caliber, Long Bolt | よります | 20-21 |
| PAS-CSHD 25S | .25 Caliber, Super Heavy Duty | イララ 今年 アプラー | 22-23 |
| PAS-C RB 25R | .25 Caliber, Self-Retracting Bolt | | 24-25 |
| PAS-C IF 25S | .25 Caliber, Handheld Impact Fire | *** | 26-27 |
| PAS-CLH IF 25S | .25 Caliber, Long Handle Impact Fire | AT AT AT | 26-27 |






Power Actuated Stunner (PAS) TYPE-P Standard Bolt



Suggested Cartridges: Caliber .22R

| Part No. | Description .22R | | Rounds Per Pkg | Cartridge Photos | Applications |
|------------|----------------------------|-----------------------------|----------------|------------------|---------------|
| 3028 35595 | Pink Cartridge, 1.25 Grain | | 1000 | • !! | 100 |
| 3028 35635 | | Pink Cartridge, 1.25 Grain | 50 | | と思えまる |
| 3028 77125 | | Purple Cartridge, 2.5 Grain | 1000 | | |
| 3028 36045 | | Purple Cartridge, 2.5 Grain | 50 | | Mark Mark |
| 3028 77195 | | Green Cartridge, 3.0 Grain | 1000 | A | |
| 3028 35645 | | Green Cartridge, 3.0 Grain | 50 | • | the kind that |



| ITEM NO. | JARVIS NO. | # | DESCRIPTION | QTY |
|------------|------------|-----|-----------------------|-----|
| 3028 78241 | 1116940 | 101 | NOSEPIECE HOUSING | 1 |
| 3028 77461 | 1104539 | 102 | NOSEPIECE LOCK WASHER | 1 |
| 3028 36071 | 1104536 | 103 | RED BUMPER WASHER | 1 |
| 3028 77051 | 1171577 | 104 | STUNNING ROD BUMPER | 8 |
| 3028 77491 | 1104537 | 105 | BLUE BUMPER WASHER | 1 |
| 3028 77441 | 1120507 | 106 | STUNNING ROD | 1 |

*(225) *(226) *(227) *(228) *(227)

JARVIS

PAS-PS 22R Replacement parts

⚠ See page 32 for Safety & Maintenance Instructions.

| ITEM NO. | JARVIS NO. | # | DESCRIPTION | QTY |
|------------|------------|-----|----------------------------|-----|
| | | | | |
| 3028 77801 | 1154257 | 201 | HANDLE RETAINING BOLT | 2 |
| 3028 78301 | 1110616 | 202 | FIRING BLOCK PIVOT PIN | 1 |
| 3028 78261 | 1110618 | 203 | HAMMER PIVOT PIN | 1 |
| 3028 37181 | 3116601 | 204 | RECEIVER HOUSING .22 R | 1 |
| 3028 78361 | 1110250 | 205 | ROLL PIN | 1 |
| 3028 36771 | 3161001 | 206 | FIRING BLOCK (WITHOUT DOG) | 1 |
| 3028 78161 | 1110617 | 207 | FIRING PIN | 1 |
| 3028 78371 | 1136001 | 208 | FIRING BLOCK BUSHING | 1 |
| 3028 36781 | 1118182 | 209 | HAMMER | 1 |
| 3028 77711 | 1171579 | 210 | EXTRACTOR .22 | 1 |
| 3028 77941 | 1118181 | 211 | DOG | 1 |
| 3028 78171 | 1145030 | 212 | DOG RIVET | 1 |
| 3028 77661 | 3132042 | 213 | CATCH PLATE | 1 |
| 3028 78281 | 1110620 | 214 | RELEASE PIN DOWEL | 1 |
| 3028 77671 | 1110619 | 215 | RELEASE PIN only | 1 |
| 3028 77511 | 1114253 | 216 | RELEASE PIN SPRING | 1 |
| 3028 78781 | 1119301 | 217 | HANDLE | 1 |
| 3028 77841 | 1102775 | 218 | HANDLE COVER | 1 |

| WE HAVE REP | LACEMENT PARTS FOR ALL C | ASH SPECIAL STUNNERS |
|-------------|--------------------------|----------------------|

| ITEM NO. | JARVIS NO. | REPLACEME | NT PARTS STANDARD FOR CASH SPECIAL |
|------------|------------|-----------|------------------------------------|
| 3028 77781 | 1114254 | 216-S | STANDARD RELEASE PIN SPRING |
| 3028 77701 | 3110010 | 214S/215S | STANDARD RELEASE PIN ASSEMBLY |
| 3028 78151 | 1110622 | 214-S | STANDARD RELEASE PIN DOWEL |
| 3028 78201 | 1118002 | 209-S | STANDARD HAMMER |

| ITEM NO. | JARVIS NO. | # | DESCRIPTION | QTY | | | |
|------------|--|--------|------------------------------|------|-----|--|--|
| 3028 78491 | 1110239 | 219 | ROLL PIN | 1 | | | |
| 3028 78451 | 1110633 | 220 | TRIGGER PIVOT PIN | 1 | | | |
| 3028 77921 | 1118183 | 221 | TRIGGER | 1 | | | |
| 3028 78441 | 1110621 | 222 | TRIGGER PIN | 1 | | | |
| 3028 78381 | 1114251 | 223 | TRIGGER RETURN SPRING | 1 | | | |
| 3028 77381 | 1114252 | 224 | EJECTOR SPRING | 1 | | | |
| 3028 78551 | 1104001 | 225 | RIBBED LOCK WASHER (PAIR) | 1 | | | |
| 3028 78561 | 1173289 | 226 | SOCKET HEAD CAP SCREW | 1 | | | |
| 3028 77951 | 1107493 | 227 | HEX NUT | 2 | | | |
| 3028 78621 | 1154258 | 228 | TRIP SCREW | 1 | | | |
| 3028 36501 | 3110009 | 214/2 | 15 RELEASE PIN ASSEMBLY | 1 | | | |
| 3028 36791 | 36791 3161561 205-208, 211-12 FIRING BLOCK & DOG | | | ASSE | MBI | | |
| 3028 36161 | 3110001 | 205, 2 | 207, 208 FIRING PIN ASSEMBLY | | | | |

(210)




Power Actuated Stunner (PAS) TYPE-P Standard Bolt



Suggested Cartridges: Caliber .25

| Part No. | Description .25 | | Rounds Per Pkg | Cartridge Photos | Applications |
|------------|-----------------|-----------------------------|----------------|------------------|--------------|
| 3028 77225 | | Pink Cartridge, 1.25 Grain | 1000 | .25R | |
| 3028 77285 | | Pink Cartridge, 1.25 Grain | 50 | .25R | は独立まる |
| 3028 35765 | | Yellow Cartridge, 2.0 Grain | 1000 | _ 4 | |
| 3028 35785 | | Yellow Cartridge, 2.0 Grain | 50 | .258 | Real Trans |
| 3028 77095 | | Blue Cartridge, 3.0 Grain | 1000 | .25R | |
| 3028 77265 | | Blue Cartridge, 3.0 Grain | 50 | .25R | are the text |




(202)

(223)

(222)

(221)




(206)

(210)

(204)

JARVIS

(205)



JARVIS

PAS-PS 25S Replacement parts

⚠ See page 32 for Safety & Maintenance Instructions.

| ITEM NO. | JARVIS NO. | # | DESCRIPTION | QTY |
|------------|------------|-----|----------------------------|-----|
| 3028 77801 | 1154257 | 201 | HANDLE RETAINING BOLT | 2 |
| 3028 78301 | 1110616 | 202 | FIRING BLOCK PIVOT PIN | 1 |
| 3028 78261 | 1110618 | 203 | HAMMER PIVOT PIN | 1 |
| 3028 37171 | 3116603 | 204 | RECEIVER HOUSING .25 S | 1 |
| 3028 78361 | 1110250 | 205 | ROLL PIN | 1 |
| 3028 36771 | 3161001 | 206 | FIRING BLOCK (WITHOUT DOG) | |
| 3028 78161 | 1110617 | 207 | FIRING PIN | 1 |
| 3028 78371 | 1136001 | 208 | FIRING BLOCK BUSHING | 1 |
| 3028 36781 | 1118182 | 209 | HAMMER | 1 |
| 3028 77601 | 1171582 | 210 | EXTRACTOR .25 | 1 |
| 3028 77941 | 1118181 | 211 | DOG | 1 |
| 3028 78171 | 1145030 | 212 | DOG RIVET | 1 |
| 3028 77661 | 3132042 | 213 | CATCH PLATE | 1 |
| 3028 78281 | 1110620 | 214 | RELEASE PIN DOWEL | 1 |
| 3028 77671 | 1110619 | 215 | RELEASE PIN only | 1 |
| 3028 77511 | 1114253 | 216 | RELEASE PIN SPRING | 1 |
| 3028 78781 | 1119301 | 217 | HANDLE | 1 |
| 3028 77841 | 1102775 | 218 | HANDLE COVER | 1 |

| WE HAVE | REPLACEMI | ENT PARTS FOR ALL CASH SPECIAL STUNNERS |
|----------|------------|---|
| ITEM NO. | JARVIS NO. | REPLACEMENT PARTS STANDARD FOR CASH SPECIAL |

| 3028 77781 | 1114254 | 216-S | STANDARD RELEASE PIN SPRING |
|------------|---------|-----------|-------------------------------|
| 3028 77701 | 3110010 | 214S/215S | STANDARD RELEASE PIN ASSEMBLY |
| 3028 78151 | 1110622 | 214-S | STANDARD RELEASE PIN DOWEL |
| 3028 78201 | 1118002 | 209-S | STANDARD HAMMER |

| ITEM NO. | JARVIS NO. | # | DESCRIPTION | QTY | |
|------------|------------|------------------------------|--------------------------------|------|----|
| 3028 78491 | 1110239 | 219 | ROLL PIN | 1 | |
| 3028 78451 | 1110633 | 220 | TRIGGER PIVOT PIN | 1 | |
| 3028 77921 | 1118183 | 221 | TRIGGER | 1 | |
| 3028 78441 | 1110621 | 222 | TRIGGER PIN | 1 | |
| 3028 78381 | 1114251 | 223 | TRIGGER RETURN SPRING | 1 | |
| 3028 77381 | 1114252 | 224 | EJECTOR SPRING | 1 | |
| 3028 78551 | 1104001 | 225 | RIBBED LOCK WASHER (PAIR) | 1 | |
| 3028 78561 | 1173289 | 226 | SOCKET HEAD CAP SCREW | 1 | |
| 3028 77951 | 1107493 | 227 | HEX NUT | 2 | |
| 3028 78621 | 1154258 | 228 | TRIP SCREW | 1 | |
| 3028 36501 | 3110009 | 214/215 RELEASE PIN ASSEMBLY | | | |
| 3028 36791 | 3161561 | 205-2 | 208, 211-12 FIRING BLOCK & DOG | ASSE | ИE |
| 3028 36161 | 3110001 | 205, 2 | 207, 208 FIRING PIN ASSEMBLY | | |




Power Actuated Stunner (PAS) TYPE-P Heavy Duty, Standard Bolt



Suggested Cartridges: Caliber .25R

| Part No. | Description .25R | Rounds PerPkg | Cartridge Photos | Applications | | |
|------------|-----------------------------|---------------|-------------------|--------------|--|--|
| 3028 77225 | Pink Cartridge, 1.25 Grain | 1000 | | . As -3 | | |
| 3028 77285 | Pink Cartridge, 1.25 Grain | 50 | O | はま 耳 多耳 | | |
| 3028 77275 | Yellow Cartridge, 2.0 Grain | 1000 | <u>o</u> <u>û</u> | | | |
| 3028 77735 | Yellow Cartridge, 2.0 Grain | 50 | | May May | | |
| 3028 77095 | Blue Cartridge, 3.0 Grain | 1000 | <u> </u> | | | |
| 3028 77265 | Blue Cartridge, 3.0 Grain | 50 | · • • | | | |
| 3028 77085 | Orange Cartridge, 3.5 Grain | 1000 | <u> </u> | 777 | | |
| 3028 77245 | Orange Cartridge, 3.5 Grain | 50 | 🐸 📗 | the way | | |



WE HAVE REPLACEMENT PARTS FOR ALL CASH SPECIAL STUNNERS

3028 36791

3028 36821

3161561

3180003

205-208, 211, 212 FIRING BLOCK & DOG ASSEMBLY

CONTAINER AND TOOLS PACKAGE

1

3028 77511

3028 78781

1114253

1119301

216

217

RELEASE PIN SPRING

HANDLE




Power Actuated Stunner (PAS) TYPE-P Heavy Duty, Long Bolt



Suggested Cartridges: Caliber .25R

| Part No. | Description .25R | Rounds Per Pkg | Cartridge Photos | Applications | |
|------------|-----------------------------|----------------|-------------------|--------------|--|
| 3028 77225 | Pink Cartridge, 1.25 Grain | 1000 | | とき きょ | |
| 3028 77285 | Pink Cartridge, 1.25 Grain | 50 | | A SE WELL LA | |
| 3028 77275 | Yellow Cartridge, 2.0 Grain | 1000 | <u>o</u> <u>Å</u> | THE TOTAL | |
| 3028 77735 | Yellow Cartridge, 2.0 Grain | 50 | | | |
| 3028 77095 | Blue Cartridge, 3.0 Grain | 1000 | <u> </u> | | |
| 3028 77265 | Blue Cartridge, 3.0 Grain | 50 | | | |
| 3028 77085 | Orange Cartridge, 3.5 Grain | 1000 | <u>.</u> | | |
| 3028 77245 | Orange Cartridge, 3.5 Grain | 50 | | | |



WE HAVE REPLACEMENT PARTS FOR ALL CASH SPECIAL STUNNERS

3028 77511

3028 78781

1114253

1119301

216

217

RELEASE PIN SPRING

HANDLE

3161561 205-208, 211, 212 FIRING BLOCK & DOG ASSEMBLY

CONTAINER AND TOOLS PACKAGE

3028 36791

3028 36821

3180003




Power Actuated Stunner (PAS) TYPE-P with Concussion Head



Suggested Cartridges: Caliber .25R

| Part No. | Description .25R | Rounds PerPkg | Cartridge Photos | Applications |
|------------|-----------------------------|---------------|------------------|--------------|
| 3028 77225 | Pink Cartridge, 1.25 Grain | 1000 | • A | 400 |
| 3028 77285 | Pink Cartridge, 1.25 Grain | 50 | | 4 8, 600 14 |
| 3028 77275 | Yellow Cartridge, 2.0 Grain | 1000 | o û | |
| 3028 77735 | Yellow Cartridge, 2.0 Grain | 50 | | |



WE HAVE REPLACEMENT PARTS FOR ALL CASH SPECIAL STUNNERS

3028 36791

3028 36821

3180003

3161561 205-208, 211, 212 FIRING BLOCK & DOG ASSEMBLY

CONTAINER AND TOOLS PACKAGE

RELEASE PIN SPRING

HANDLE

216

217

3028 77511

3028 78781

1114253

1119301



Power Actuated Stunner (PAS) TYPE-P Veterinary Kit



- Comfortable, ergonomically designed handle.
- Diverse applications, from smaller to larger sized livestock.
- Renders animal insensible to pain before slaughter.
- Simple to use, operate and maintain Ruggedly built for long service life.
- Includes Standard, Medium, Long and Concussion Heads for multiple stunning uses.
- Different cartridge strengths available, depending on usage.


Suggested Cartridges, Caliber .25R

| Part No. | Description .25R | Rounds Per Pkg | Cartridge Photos | Applications | |
|------------|-----------------------------|----------------|------------------|--------------|--|
| 3028 77225 | Pink Cartridge, 1.25 Grain | 1000 | | 1 00 00 P | |
| 3028 77285 | Pink Cartridge, 1.25 Grain | 50 | | A 25 WHO 14 | |
| 3028 77275 | Yellow Cartridge, 2.0 Grain | 1000 | o 🖺 | A TO | |
| 3028 77735 | Yellow Cartridge, 2.0 Grain | 50 | | | |
| 3028 77095 | Blue Cartridge, 3.0 Grain | 1000 | <u> </u> | | |
| 3028 77265 | Blue Cartridge, 3.0 Grain | 50 | | A RO MI | |
| 3028 77085 | Orange Cartridge, 3.5 Grain | 1000 | <u> </u> | | |
| 3028 77245 | Orange Cartridge, 3.5 Grain | 50 | 9 | act we wa | |



01

SEE PAGE 41 for additional cleaning & maintenance tools



Thoroughly read and understand all safety instructions and ensure that the stunner is in proper working condition Δ before attempting to use this stunner.

- 4. Steel Wire Barrel Brush
- 5. Spanner (Wrench)
- 6. Manual Extractor/Pry Bar
- 7. Push Rod
- 8. Pick
- 9. Undercut Scraper/Cleaner
- 10. Breech Scraper/Cleaner Assembly
- 11. Hex Key Wrench
- 12. Wire Hand Brush
- 13. 14 mm Cone Wrench
- 14. 16 mm Cone Wrench
- 15. Gun Oil. 4oz. bottle
- 16. Anti-Seize Grease. 4oz. tube

Stunner & Accessories:

- 17. .25 Caliber P-Type Stunner with Handle
- 18. HD Standard Bolt
- 19. HD Medium Bolt
- 20. HD Long Bolt
- 21. Concussion Head
- 22-25. Power Load cartridges, 1x each, 50/tin
 - .25 Pink. 1.25 Grain
 - .25 Yellow. 2.0 Grain
 - .25 Blue, 3.0 Grain
 - .25 Orange, 3.5 Grain




Power Actuated Stunner (PAS) TYPE-C Concussion, Non-Penetrating



Suggested Cartridges: Caliber .22R

| Part No. | Description .22R | Rounds per Pkg | Cartridge photo | Applications |
|------------|----------------------------|----------------|-----------------|--------------|
| 3028 35595 | Pink Cartridge, 1.25 Grain | 1000 | | |
| 3028 35635 | Pink Cartridge, 1.25 Grain | 50 | | A D L SOLL |






Power Actuated Stunner (PAS) TYPE-C Standard Bolt




Suggested Cartridges: Caliber .25S

| Part No. | Description .25\$ | | Rounds per Pkg | Cartridge photos | Applications |
|------------|-------------------|--|----------------|------------------|--------------|
| 3028 35765 | | Yellow Cartridge 2 Grain | 1000 | | |
| 3028 35555 | | Black Cartridge 4 Grain | 1000 | | |
| 3028 35845 | | Black Cartridge HMF (Lead Free) 5 Grain | 1000 | (*) | |



⚠ See

| | 3028 77891 | 1110006 | 110 | SAFETY ROLL PIN | 1 | ı |
|---|------------|---------|-----|-------------------------|---|---|
| | 3538 00211 | 410924 | 111 | PULL LOCK O-RING WASHER | 1 | |
| | 3028 77471 | 1171434 | 112 | FIRING PIN PULL | 1 | |
| | 3028 77531 | 1114227 | 113 | PULL BUFFER | 1 | |
| IADVIC | 3028 77621 | 1136408 | 114 | PULL BUSHING | 1 | |
| JARVIS | 3028 77351 | 1171435 | 115 | INNER SAFETY CAP | 1 | |
| | 3028 77551 | 1136409 | 116 | PULL SPLIT BUSH (PAIR) | 1 | |
| PAS-CS 25S | 3538 00201 | 410918 | 117 | SMALL O-RING | 1 | |
| Replacement parts | 3028 77101 | 1116857 | 118 | BREECH CAP | 1 | |
| Replacement paris | 3028 78141 | 1114226 | 119 | PLUNGER SPRING | 1 | |
| ee page 33 for Safety & Maintenance Instructions. | 3028 77691 | 1139086 | 120 | EXTRACTOR PLUNGER | 1 | |
| (205) (207) (208) (207) | 209 | | | | | |



WE HAVE REPLACEMENT PARTS FOR ALL CASH MAGNUM STUNNERS

QTY




Power Actuated Stunner (PAS) TYPE-C Long Bolt



Suggested Cartridges: Caliber .25S

| Part No. | Description .25\$ Rounds p | | Rounds per Pkg | Cartridge photos | Applications |
|------------|----------------------------|--|----------------|------------------|--|
| 3028 35765 | | Yellow Cartridge 2 Grain | 1000 | 3 | A TO |
| 3028 35555 | | Black Cartridge 4 Grain | 1000 | @ | |
| 3028 35845 | | Black Cartridge HMF (Lead Free) 5 Grain | 1000 | • | Was the same of th |



| (119) | 3028 77171 | 1110637 | 106 | FIRING PIN | 1 |
|-------------------|------------|---------|-----|-------------------------|---|
| | 3028 77211 | 1114225 | 107 | FIRING PIN SPRING | 1 |
| <i>)</i>) | 3538 00221 | 410947 | 108 | SAFETY O-RING | 1 |
| | 3028 77371 | 1171436 | 109 | OUTER SAFETY CAP | 1 |
| | 3028 77891 | 1110006 | 110 | SAFETY ROLL PIN | 1 |
| | 3538 00211 | 410924 | 111 | PULL LOCK O-RING WASHER | 1 |
| | 3028 77471 | 1171434 | 112 | FIRING PIN PULL | 1 |
| | 3028 77531 | 1114227 | 113 | PULL BUFFER | 1 |
| | 3028 77621 | 1136408 | 114 | PULL BUSHING | 1 |
| IADVIC | 3028 77351 | 1171435 | 115 | INNER SAFETY CAP | 1 |
| JARVIS | 3028 77551 | 1136409 | 116 | PULL SPLIT BUSH (PAIR) | 1 |
| DAC OL OEC | 3538 00201 | 410918 | 117 | SMALL O-RING | 1 |
| PAS-CL 25S | 3028 77101 | 1116857 | 118 | BREECH CAP | 1 |
| lacement parts | 3028 78141 | 1114226 | 119 | PLUNGER SPRING | 1 |
| idoeilielii palis | 3028 77691 | 1139086 | 120 | EXTRACTOR PLUNGER | 1 |

See page 33 for Safety & Maintenance Instructions. 209 207 208 207 206 ITEM NO. JARVIS NO. **DESCRIPTION** QTY 3028 77341 1109202 201 COLLAR 3028 77521 1171438 202 **COLLAR BALL** 3028 77561 1114228 203 **COLLAR SPRING** 3028 77421 1110583 204 **COLLAR RETAINING PIN** 1 3028 77611 1116001 205 BARREL/NOSEPIECE LONG 1 3028 77361 1104509 206 BARREL LOCK WASHER 1 3028 77111 1171432 207 BLACK BUFFER, HARD 2 3028 77251 1171433 208 RED BUFFER, SOFT 3028 77761 1120001 209 STUNNING ROD LONG BOLT

WE HAVE REPLACEMENT PARTS FOR ALL CASH MAGNUM STUNNERS

QTY

1

1

1

1

Repl




Power Actuated Stunner (PAS) TYPE-C Super Heavy Duty



Suggested Cartridges: Caliber .25

| Part No. | Description .25 caliber | Rounds per Pkg | Cartridge photos | Applications |
|------------|--|----------------|------------------|--------------|
| 3028 77315 | Red Cartridge 6 Grain | 1000 | .25R | |
| 3028 35555 | Black Cartridge 4 Grain | 1000 | .25S | |
| 3028 35845 | Black Cartridge HMF (Lead Free) 5 Grain | 1000 | ● | 1-10 mm |




PAS-CSHD 25S Replacement parts

⚠ See page 33 for Safety & Maintenance Instructions.

120

| ITEM NO. | JARVIS NO. | # | DESCRIPTION | QTY |
|------------|------------|-----|-------------------------|-----|
| 3028 37191 | 3116029 | 101 | BREECH HOUSING, HD | 1 |
| 3028 77451 | 1171437 | 102 | EXTRACTOR .25 CALIBER | 1 |
| 3028 77321 | 1102673 | 103 | BREECH COVER | 1 |
| 3028 77571 | 1114224 | 104 | TRIGGER SPRING | 1 |
| 3028 77331 | 1118176 | 105 | TRIGGER | 1 |
| 3028 77171 | 1110637 | 106 | FIRING PIN | 1 |
| 3028 77211 | 1114225 | 107 | FIRING PIN SPRING | 1 |
| 3538 00221 | 410947 | 108 | SAFETY O-RING | 1 |
| 3028 77371 | 1171436 | 109 | OUTER SAFETY CAP | 1 |
| 3028 77891 | 1110006 | 110 | SAFETY ROLL PIN | 1 |
| 3538 00211 | 410924 | 111 | PULL LOCK O-RING WASHER | 1 |
| 3028 77471 | 1171434 | 112 | FIRING PIN PULL | 1 |
| 3028 77531 | 1114227 | 113 | PULL BUFFER | 1 |
| 3028 77621 | 1136408 | 114 | PULL BUSHING | 1 |
| 3028 77351 | 1171435 | 115 | INNER SAFETY CAP | 1 |
| 3028 77551 | 1136409 | 116 | PULL SPLIT BUSH (PAIR) | 1 |
| 3538 00201 | 410918 | 117 | SMALL O-RING | 1 |
| 3028 36931 | 1116012 | 118 | BREECH CAP | 1 |
| 3028 78141 | 1114226 | 119 | PLUNGER SPRING | 1 |
| 3028 77691 | 1139086 | 120 | EXTRACTOR PLUNGER | 1 |



WE HAVE REPLACEMENT PARTS FOR ALL CASH MAGNUM STUNNERS




Power Actuated Stunner (PAS) TYPE-C (RB) RETRACTING BOLT



- Control Handle: Single Trigger, Manual Operation.
- Automatic bolt retraction.
- Overall Dimensions: 14.40 inches x 2.13 inches (366 x 54 mm)
- Weight: 6.50-lbs.

Suggested Cartridges: Caliber .25R

| Part No. | D | escription .25R | Rounds per Pkg | Cartridge photos | Applications |
|------------|---|-----------------------------|----------------|------------------|--------------|
| 3028 77275 | | Yellow Cartridge, 2.0 Grain | 1000 | o û | |
| 3028 77735 | _ | Yellow Cartridge, 2.0 Grain | 50 | | |
| 3028 77095 | | Blue Cartridge, 3.0 Grain | 1000 | <u> </u> | |
| 3028 77265 | | Blue Cartridge, 3.0 Grain | 50 | | and the text |
| 3028 77085 | | Orange Cartridge, 3.5 Grain | 1000 | <u> </u> | |
| 3028 77245 | | Orange Cartridge, 3.5 Grain | 50 | | ack has less |
| 3028 77935 | | Black Cartridge, 4.0 Grain | 1000 | <u> </u> | |
| | | | | | אווו שוא אוא |




JARVIS PAS-C RB 25R

(120)

Replacement parts

A See page 33 for Safety & Maintenance Instructions.

| ١. | ITEM NO. | JARVIS NO. | # | DESCRIPTION | QTY |
|----|------------|------------|-----|-------------------------|-----|
| | 3028 36461 | 3116590 | 101 | BREECH HOUSING | 1 |
| | 3028 77451 | 1171437 | 102 | EXTRACTOR .25 CALIBER | 1 |
| | 3028 77321 | 1102673 | 103 | BREECH COVER | 1 |
| | 3028 77571 | 1114224 | 104 | TRIGGER SPRING | 1 |
| | 3028 77331 | 1118176 | 105 | TRIGGER | 1 |
| | 3028 77171 | 1110637 | 106 | FIRING PIN | 1 |
| | 3028 77211 | 1114225 | 107 | FIRING PIN SPRING | 1 |
| | 3538 00221 | 410947 | 108 | SAFETY O-RING | 1 |
| | 3028 77371 | 1171436 | 109 | OUTER SAFETY CAP | 1 |
| | 3028 77891 | 1110006 | 110 | SAFETY ROLL PIN | 1 |
| | 3538 00211 | 410924 | 111 | PULL LOCK O-RING WASHER | 1 |
| | 3028 77471 | 1171434 | 112 | FIRING PIN PULL | 1 |
| | 3028 77531 | 1114227 | 113 | PULL BUFFER | 1 |
| | 3028 77621 | 1136408 | 114 | PULL BUSHING | 1 |
| | 3028 77351 | 1171435 | 115 | INNER SAFETY CAP | 1 |
| | 3028 77551 | 1136409 | 116 | PULL SPLIT BUSH (PAIR) | 1 |
| | 3538 00201 | 410918 | 117 | SMALL O-RING | 1 |
| | 3028 77101 | 1116857 | 118 | BREECH CAP | 1 |
| | 3028 78141 | 1114226 | 119 | PLUNGER SPRING | 1 |
| | 3028 77691 | 1139086 | 120 | EXTRACTOR PLUNGER | 1 |





Power Actuated Stunners (PAS) TYPE-C IMPACT FIRE



.25 Caliber, HAND HELD, HEAVY DUTY PAS-C IF 25S Item No. 3028 36471 Jarvis No. 4144072


.25 Caliber, LONG HANDLE, **HEAVY DUTY** PAS-CLH IF 25S Item No. 3028 36021 Jarvis No. 4144071

- 31" long handle, perfect for accessing large animals in stunning pens, lead-ups and trailers.
- Penetrating bolt, contact fires upon impacting animal's skull.
- Standard safety lock for added operator protection.
- Positive retraction of bolt after firing.
- Penetrating Shaft Diameter: .450 in (11.43mm) rod.



Suggested Cartridges: Caliber .25S

| Part No. | Description .25\$ | | Description .25\$ | | Description .25\$ | | Description .25\$ Rounds per Pkg | | Cartridge photo | Applications |
|------------|-------------------|-------------------------|-------------------|---|-------------------|--|----------------------------------|--|-----------------|--------------|
| 3028 35555 | | Black Cartridge 4 Grain | 1000 | * | | | | | | |





Power Actuated Stunner (PAS) Stun Tester



STUN TESTER Item No. 3028 35941 **JARVIS NO. 4116001**

- Model: AST 106
- Complies with the most stringent requirements for audit data collection.
- Easy to use intuitive operation.
- Exportable data log for test audits.

EXAMPLE: Exportable data log for stun test tracking

| Stun Test Data Records | | | | | | | |
|------------------------|--------------|----------|-----------------|----------------|-------|--|--|
| Date/Time | Stunner # | Serial # | Power Load Code | Operator ID | SPEED | | |
| | ** | Serial # | Power Load Code | IU | SPEED | | |
| 5/4/2016 | | | | | | | |
| 8:19 | 16 | 110016 | 7 | 1234 | 191 | | |
| 5/4/2016 | | | | | | | |
| 8:24 | 16 | 110016 | 7 | 1234 | 179 | | |
| 5/4/2016 | | | | | | | |
| 8:38 | 16 | 110016 | 9 | 1234 | 196 | | |
| 5/4/2016 | _ | | | | | | |
| 9:04 | 17 | 110017 | 7 | 1235 | 184 | | |
| | | | | | | | |







Stun Tester compatible with Type-C and Type-P **Power Actuated Stunners** & other captive bolt tools with no additional adaptors needed.

> Not for use with Pneumatic Stunners.

Stun Tester Safety & Installation Instructions



Λ

SAFETY MESSAGES TO AVOID INJURY

Ensure that all employees who use this tester are trained in the proper use of the PAS Cartridge Stunner and are aware of the dangers that may arise if they do not follow procedures outlined in the tester and stunner operating manuals.

Remove and repair any PAS Cartridge Stunner that malfunction. All personnel must be instructed to remove any malfunctioning equipment.

The PAS Cartridge Stunner Tester is designed and intended to be powerful. This fact should be obvious to your employees, but you must emphasize it to them.

Ensure that all employees are instructed to stand clear of the tester during its use, and to never put fingers, hands or other parts of the body directly in front of the PAS Cartridge Stunner. Ensure eye and ear protection is worn at all times when operating the PAS Cartridge Stunner.

Never make modifications or alterations to the tester. *Replace any missing or illegible labels.*

Follow our installation and maintenance instructions for proper installation and care of the tester.

Avoid injury. Do not permit the tester to be misused.

If you resell or distribute a Jarvis product, you must provide the purchaser with the appropriate safety sheets and tool brochure. Additional copies of safety sheets and tool brochures will be provided upon request.

SAFETY MESSAGES TO OPERATORS, MAINTENANCE AND CLEANUP PERSONNEL



🔼 REMOVE ANY MALFUNCTIONING TOOL FROM SERVICE




REPORT ANY PROBLEMS TO YOUR SUPERVISOR


Disconnect the power in accordance with OSHA's lockout/tagout procedures (29 CFR 1910.147) before performing any repair, maintenance or cleanup.

Never put fingers, hands or other parts of the body directly in front of the PAS Cartridge Stunner.

Always wear eye and ear protection when operating the tester. Never squeeze the trigger while inserting the PAS Cartridge Stunner into the tester.



Tester Stand



Power Requirements 30 W, 115 V / 0.3 A or 220 V /0.2 A

Operating Voltage 115 V, 1 phase, 60 Hz

230 V, 1 phase, 50/60 Hz

Overall Dimensions (Ø x h or w x h x dp)

Test Stand 7 in x 10 in (178 mm x 254 mm)

Control Box 12 x 10 x 4 in (305 x 254 x 102 mm)

Weight:

Test Stand 23 lbs (10.4kg)

Control Box 5 lbs (2.4kg)

INSTALLATION INSTRUCTIONS



ALWAYS TURN THE POWER OFF IN ACCORDANCE WITH OSHA'S LOCKOUT/TAGOUT PROCEDURES (29 CFR 1910.147) BEFORE PERFORMING ANY MAINTENANCE OR REPAIRS.

- 1 Mount the Model AST-106 tester securely on a bench or tabletop in the vicinity of where the Model PAS Stunner is being used and/or maintained. Be sure to mount the safety plate (item 118) between the Model AST-106 and the bench.
- 1.1 Use the three (9/16) clearance holes to secure the housing and safety plate.
- 1.2 Make sure that the top of the housing is at a convenient height to facilitate insertion and extraction of the PAS Stunner.
- 2 Mount the control box in the vicinity of the test stand. A six foot long cord with connector is provided.
- 3 The power requirement for the tester is 30 Watts at 115 VAC, 50/60 Hz or 230 VAC, 50/60 Hz

All wiring must be done in accordance with the national, state and local electrical codes.

4 Connect the control box to the test stand with the cable and connector provided.

CONTROL BOX SETUP & ADDITIONAL USAGE INSTRUCTIONS AVAILABLE UPON REQUEST


POWER ACTUATED STUNNERS (PAS) Power Load Cartridge Chart



| | Reduced Design Cartridges .22 Caliber | | | | | | |
|------------|---------------------------------------|-----------------------------|----------------|--|--------------|--|--|
| ITEM NO. | | DESCRIPTION .22R | ROUNDS PER PKG | | APPLICATIONS | | |
| 3028 35595 | | Pink Cartridge, 1.25 Grain | 1000/box | | | | |
| 3028 35635 | | Pink Cartridge, 1.25 Grain | 50/tin | | ルス銀工をよ | | |
| 3028 77125 | | Purple Cartridge, 2.5 Grain | 1000/box | | 1 | | |
| 3028 36045 | | Purple Cartridge, 2.5 Grain | 50/tin | | | | |
| 3028 77195 | | Green Cartridge, 3.0 Grain | 1000/box | | | | |
| 3028 35645 | | Green Cartridge, 3.0 Grain | 50/tin | | | | |

| | Reduced Des | sign Cartridg | ges .25 | Caliber |
|------------|-----------------------------|----------------|----------|--------------|
| ITEM NO. | DESCRIPTION .25R | ROUNDS PER PKG | | APPLICATIONS |
| 3028 77225 | Pink Cartridge, 1.25 Grain | 1000/box | | |
| 3028 77285 | Pink Cartridge, 1.25 Grain | 50/tin | | ルイボスラス |
| 3028 77275 | Yellow Cartridge, 2.0 Grain | 1000/box | (O) | |
| 3028 77735 | Yellow Cartridge, 2.0 Grain | 50/tin | | |
| 3028 77095 | Blue Cartridge, 3.0 Grain | 1000/box | | |
| 3028 77265 | Blue Cartridge, 3.0 Grain | 50/tin | | |
| 3028 77085 | Orange Cartridge, 3.5 Grain | 1000/box | | |
| 3028 77245 | Orange Cartridge, 3.5 Grain | 50/tin | | |
| 3028 77935 | Black Cartridge, 4.0 Grain | 1000/box | | |
| 3028 78135 | Black Cartridge, 4.0 Grain | 50/tin | | |
| 3028 35685 | Green Cartridge, 4.5 Grain | 1000/box | <u> </u> | |
| 3028 35715 | Green Cartridge, 4.5 Grain | 50/tin | | |
| 3028 77315 | Red Cartridge, 6.0 Grain | 1000/box | | |
| 3028 35735 | Red Cartridge, 6.0 Grain | 50/tin | | |

| Straight Design Cartridges .25 Caliber | | | | | | |
|--|--|----------------------------------|-----------------------|----------|--------------|--|
| ITEM NO. | | DESCRIPTION .25S | ROUNDS PER PKG | | APPLICATIONS | |
| 3028 35765 | | Yellow Cartridge, 2.0 Grain | 1000/box | . 4 | | |
| 3028 35785 | | Yellow Cartridge, 2.0 Grain | 50/tin | | | |
| 3028 35555 | | Black Cartridge, 4.0 Grain | 1000/box | | | |
| 3028 35835 | | Black Cartridge, 4.0 Grain | 50/tin | * | | |
| 3028 35845 | | Black Cartridge, HMF, (lead free | e) 5.0 Grain 1000/box | | (| |
| 3028 35895 | | Red Cartridge NI, (Nickel) 6.0 (| Grain 1000/box | * | | |



SAFETY MESSAGES TO EMPLOYER AND SAFETY DIRECTOR



Jarvis Products Corporation and Bunzl shall not be responsible for any death, physical injury or property damage that is the result of the proper or improper use of this stunner.

This tool is classified as a power operated stunner. It has only one intended purpose – the stunning of live animals. Failure to read and properly execute the instructions and warnings in this manual could result in serious injury, death or damage to property.

Always treat this stunner as if it were loaded.

Do not attempt to practice loading or unloading with live cartridges without a thorough understanding of the safe operation of this stunner.

Always store and carry this stunner without live cartridges and with the safety cap rotated into the "S" safe position. Failure to do so could result in an unintentional discharge.

When you extend the cocking cap and depress the trigger, you must expect the stunner to fire and take full responsibility for your actions.

Keep out of reach of children.



SAFETY MESSAGES TO OPERATORS, MAINTENANCE AND CLEANUP PERSONNEL

Read through the entire manual before attempting to use the stunner.

When transporting this stunner, separate the breech housing from the breech cap housing to prevent the possibility of accidentally firing the stunner. Do not reassemble the housings until ready to load and fire the stunner.

Never carry loose cartridges outside of the ammunition canister or packaging container. Accidental discharge could occur.

Always treat this power actuated stunner as if it were loaded.

Never put your hand on the trigger until you are ready to use the stunner.

Never point this power actuated stunner at anything you do not intend to stun. Keep the nose pointed in a safe direction.



▲WARNING

Never take anyone's word that this power actuated stunner is unloaded. Clear it yourself with hand off the trigger and the nose pointed in a safe direction. Rotate outer safety cap to the "S" safe position. Remove breech housing while holding the rubber breech locking sleeve. Visually check to insure that no round is in the breech housing. If there is one, remove it.

Always ensure that stunning rod and nosepiece housing are clear of obstructions. Shooting a blocked power actuated stunner can result in serious injury or death and damage to the stunner.

Never carry the power actuated stunner cocked, loaded and ready to fire, as this practice could easily result in an unintentional discharge.

Do not carry a loaded stunner with a live round in the chamber while walking, running or crossing any obstacle where there is any possibility of slipping or falling, as this could lead to a possible unintentional discharge.

Never place the stunner against any hard or flat surface. The recoil could result in physical injury, death or property damage.

Always ensure that this power actuated stunner is in top working condition and that no internal parts have been damaged as a result of corrosion, improper maintenance or mishandling. If evidence of these conditions exist, have the stunner inspected by a competent person prior to use.

Always wear proper hearing and eye protection when using the power actuated stunner.

Never drink alcoholic beverages or take drugs prior to or during use or handling of this power actuated stunner.

Seek a doctor's advice if you are taking medicine prior to engaging in any stunning activity.

Never leave a loaded power actuated stunner unattended.

Always ensure the power actuated stunner is unloaded and the outer safety cap is in the "S" safe position before laying it down or handing it to someone else.

Always keep the stunner in "S" safe position until ready to fire. Immediately unload and clear this stunner when stunning sequence has been completed.

Always make sure the stunner is unloaded before cleaning.

Power Actuated Stunners (PAS) TYPE-P Instructions

OPERATION INSTRUCTIONS

Thoroughly read and understand all safety instructions and ensure that the stunner is in proper working condition before attempting to use this stunner.

1. Always keep the stunner pointed in a safe direction.

- 12. Holding stunner by its handle (item 218), retract hammer (item 209) until it clicks and locks in place. While still holding handle (item 218), retract firing block assembly (item 206) until it clicks in place. Stunner in now considered to be in "safe" mode. The stunner will not discharge if the trigger (item 221) is pulled. The cartridge breech hole in receiver housing (item 204) should now be exposed.
 - 3. Ensure cartridge breech hole has no obstructions.
 - 4. Load appropriate cartridge for your application. Never exceed the maximum specified grain load for your stunner. Maximum permissible grain load is etched on the receiver housing (item 204).
 - 5. When ready to discharge the stunner, move the firing block assembly (item 206) forward until it clicks into place, covering the breech hole in the receiver housing (item 204). The stunner is now in the "fire" position.
 - 6. Squeeze trigger (item 221) to activate stunner.
 - 7. Fully retract hammer (item 209) and firing block assembly (item 206) to remove spent cartridge.
 - 8. Leave stunner in "safe" position until ready to stun again.

MAINTENANCE INSTRUCTIONS



Read thoroughly the entire manual before attempting to perform maintenance on the stunner. Always treat the stunner as if it were loaded. Make sure there is no cartridge in the receiver housing.

PRIOR TO USE OR DAILY:

Refer to cleaning tools supplied with stunner.

- 1. Clean stunning rod (item 106), nosepiece housing (item 101) and receiver housing (item 204) using supplied cleaning tools and user supplied gun powder solvent.
- 2. Wipe all metal surfaces with rag and gun oil.
- 3. Do not apply gun oil to stunning rod bumpers (item 104) or bumper washers (items 103 and 105).
- 4. Examine stunning rod bumpers (item 104), red bumper washer (item 103), blue bumper washer (item 105) and nosepiece lock washer (item 102). Replace if worn.
- 5. Put a drop of oil in the hole in the back of hammer (item 209). This hole leads directly to the hammer pivot pin (item 203).
- 6. Put a drop of oil on each side of the firing block assembly (item 206) where it slides through the receiver housing (item 204).

PISTOL DISASSEMBLY:

- 1. Remove nosepiece housing (item 101).
- 2. Remove stunning rod (item 106), blue bumper washer (item 105), stunning rod bumpers (item 104) and red bumper washer (item 103) from receiver housing (item 204).
- 3. Remove nosepiece lock washer (item 102) from nosepiece housing (item 101).
- 4. Release and remove catch plate assembly (item 213) by pushing the curled tab down.
- 5. Remove hammer and firing block pivot pins (items 202 and 203).
- 6. Remove hammer (item 209).
- 7. Remove firing block assembly (item 206), extractor (item 210), dog (item 211), dog rivet (item 212), firing pin (item 207), firing block bushing (item 208) and roll pin (item 205) as an assembly.
- 8. Remove hex nuts (item 227) and two handle retaining bolts (item 201).

- 9. Remove handle assembly (items 214-226).
- 10. Remove release pin (item 215) and release pin spring (item 216) from handle assembly.
- 11. Further disassembly is usually not required.

FIRING BLOCK AND FIRING PIN REMOVAL AND REPLACEMENT:

- 1. Remove firing block assembly (item 206) from receiver housing (item 204) as described above.
- 2. Remove extractor (item 210) from firing block assembly (item 206).
- 3. Scribe a line across firing block bushing (item 208) and firing block assembly (item 206) to ensure proper orientation of bushing during reassembly. This is required to facilitate reinstallation of roll pin (item 205).
- 4. Press out roll pin (item 205).
- 5. Using a soft drive pin, press on rounded tip of firing pin (item 207) to remove it and firing block bushing (item 208) simultaneously.
- 6. Install new firing pin (item 207) into firing block assembly (item 206), round end first.
- 7. Install firing block bushing (item 208) while keeping scribe lines in bushing and firing block assembly aligned.
- 8. Reinstall or replace roll pin (item 205).

PISTOL REASSEMBLY:

- 1. Install release pin spring (item 216) onto release pin (item 215).
- 2. Insert release pin and spring into handle (item 217) with flat side of pin on top.
- 3. Install handle assembly (items 214-226) into receiver housing (item 204).
- 4. Insert two handle retaining bolts (item 201) and secure with hex nuts (item 227), finger tight.
- 5. Assemble extractor (item 210) to firing block assembly (item 206).
- 6. Reassemble dog (item 211) and dog rivet (item 212) to firing block assembly (item 206) if they were removed.
- 7. Install firing block assembly with extractor, dog and dog rivet into receiver housing (item 204). Locate dog on top of ejector spring (item 224). The tang on extractor (item 210) goes underneath the ejector spring. The firing block assembly (item 206) goes on top of the ejector spring.
- 8. Insert firing block pivot pin (item 202).
- 9. Install hammer (item 209) onto release pin dowel (item 214).
- 10. Install hammer pivot pin (tem 203).
- 11. Tighten hex nuts (item 227) enough to not restrict movement of hammer (item 209).
- 12. Install catch plate assembly (item 213) and lock into place by pushing the curled tab up.
- 13. Install the stunning rod (item 106), blue bumper washer (item 105), stunning rod bumpers (item 104) and red bumper washer (item 103) into receiver housing (item 204).
- 14. Install nosepiece lock washer (item 102) into nosepiece housing
- 15. Install nosepiece housing (item 101) onto receiver housing (item 204) and hand tighten securely.

TROUBLESHOOTING INSTRUCTIONS STUNNER FAILS TO FIRE:

- 1. Make sure firing pin (item 207) is not damaged or obstructed.
- 2. The fit between the receiver housing (item 204) and firing block assembly (item 206) is crucial to the safe and proper operation of this stunner. If the gap between these components becomes excessive (greater than 0.003 inch/0.076 mm) both the firing block assembly (item 206) and the hammer (item 209) should both be replaced.

Power Actuated Stunners (PAS) TYPE-C Instructions

OPERATION INSTRUCTIONS



Thoroughly read and understand all safety instructions and ensure that the stunner is in proper working condition before attempting to use this stunner.



- 1. Rotate outer safety cap (item 109) until notch aligns with the green "safe" area. Stunner is now in "safe" mode.
- 2. Grasp stunner on rubber breech locking sleeve (item 103) while pointing the stunner in a safe direction.
- Grasp breech cap housing (item 118) with the other hand and unscrew in a counterclockwise direction to reveal the cartridge breech (rear end of barrel where cartridge is loaded).
- 4. Ensure cartridge breech has no obstruction.
- Retract stunning rod (item 209) by pushing with the spherical end of the cocking cap (item 112).
- Δ
- Load appropriate cartridge for your application. Do not exceed maximum specified grain load for your stunner. Maximum permissible grain load is etched on the nosepiece housing (item 205).
 - 7. Keep stunner pointed in a safe direction and reassemble breech cap housing (item 118) to breech housing (101). Hand tighten securely.
 - Arm stunner by pulling back on cocking cap (item 112) until it clicks into position.
 - 9. When completely ready to discharge stunner, rotate outer safety cap (item 109) to the "fire" position.
 - 10. To discharge stunner, use one hand to grasp stunner by rubber breech locking sleeve (item 103). Use other hand to fully depress trigger (item 105) to fire stunner.



- 11. Rotate outer safety cap (item 109) until notch aligns with the green "safe" area. Stunner is now in "safe" mode.
- 12. Remove spent cartridge by redoing steps 1-3.

MAINTENANCE INSTRUCTIONS

PRIOR TO USE OR DAILY:

Refer to package 3180239 supplied with stunner.

- Clean stunning rod (item 209) and nosepiece housing (item 205) using supplied cleaning tools and user supplied gun powder solvent.
- 2. Wipe all metal surfaces with rag and gun oil.
- 3. Do not apply gun oil to breech locking sleeve (item 103) and stunning rod bumpers (items 207 and 208).
- 4. Examine stunning rod bumpers (items 207 and 208) and nosepiece lock washer (item 206). Replace if worn.

DISASSEMBLY INSTRUCTIONS



Read thoroughly the entire manual before attempting to assemble or disassemble this stunner. Always treat the stunner as if it were loaded. Make sure there are no cartridges in the breech housing.

- Unscrew nosepiece housing (item 205) from breech housing (item 101).
- Remove nosepiece lock washer (item 206) from nosepiece housing (item 205).
- 3. Remove stunning rod (item 209) with all bumpers (items 207 and 208) from breech housing (item 101).
- 4. To remove collar (item 201), press collar retaining pin (item 204) out of nosepiece housing (item 205).
- Remove collar (item 201), ball (item 202) and rubber spring (item 203).
- 6. Slide breech locking sleeve (item 103) off breech housing (item 101).

- Depress extractor retainer (item 120) until it bottoms out and then slide cartridge extractor (item 102) off breech housing (item 101).
- Remove extractor retainer (item 120) and extractor retaining spring (item 119) from breech housing (item 101).
- 9. While depressing trigger (item 105), unscrew safety cap and firing pin assembly (items 106-116).
- 10. Remove trigger (item 105), trigger return spring (item 104) and o-ring (item 117) from breech cap housing (item 118).
- 11. Use two wrenches on flats to unscrew cocking cap (item 112) from pull bushing (item 114).
- 12. Remove rubber spring (113) from pull bushing (item 114) and o-ring (item 111) from cocking cap (item 112).
- 13. Rest tip of firing pin (item 106) and safety cap assembly (items 108-110 and 115) on a block of wood to prevent damaging firing pin tip. Push down on pull bushing (item 114) to expose split bushing halves (item 116). Remove two split bushing halves (item 116).
- 14. Slide pull bushing (item 114) over end of firing pin (item 106).
- 15. Remove firing pin spring (item 107) and safety cap assembly (items 108-110 and 115) from firing pin (item 106).
- 16. If necessary to disassemble safety cap: Align hole in safety cap assembly (items 108-110 and 115) by rotating the outer safety cap to the "fire" position. Drive stop pin (item 110) through hole inside inner safety cap (item 115). Unscrew outer safety cap (item 109) from inner safety cap (item 115). Remove and replace o-ring (item 108) and stop pin (item 110) if necessary.

ASSEMBLY INSTRUCTIONS

Reverse steps and procedures listed above.

- Grease o-ring (item 108) after installing on inner safety cap (item 115).
- 2. Assemble outer safety cap (item 109) to inner safety cap (item 115) being careful to engage the thread on the green "safe" area, so when completely secured, the notch in the outer cap aligns with the red "fire" area. Restart the thread in another thread lead if necessary.
- 3. Assemble stop pin (item 110) and press into inner safety cap (item 115) until flush with back edge of outer safety cap (item 109).
- 4. Reverse steps 15 to 6. Tighten securely.
- Grease o-ring (item 117) after installing onto breech cap housing (item 118)
- Install rubber spring (item 203), then ball (item 202) and then collar (item 201) with small end pointing away from the bumpers (items 207 and 208).
- 7. Compress collar onto ball to facilitate press fit installation of collar retaining pin (item 204).
- 8. Grease nosepiece lock washer (item 206) and insert in nosepiece housing (item 205).
- 9. Install stunning rod (item 209) with all bumpers (items 207 and 208) into breech housing (item 101).
- Screw nosepiece housing (item 205) onto breech housing (item 101) and hand tighten securely.

TROUBLESHOOTING INSTRUCTIONS

STUNNER FAILS TO FIRE:

- 1. Make sure outer safety cap (item 109) is in the "fire" position.
- Make sure breech housing (item 101) is securely engaged to breech cap housing (item 118). Secure engagement is critical to the proper operation of this stunner and prevention of cartridge misfires and rim
 - 3. Check for debris in breech cap housing (item 118) bore.
 - Check to ensure breech locking sleeve (item 103) is fully seated on breech housing (item 101).

Power Actuated Stunners (PAS) TYPE-C CONCUSSION Instructions

OPERATION INSTRUCTIONS



Thoroughly read and understand all safety instructions and ensure that the tool is in proper working condition before at-tempting to use this stunner.

- 1. Grasp stunner on nosepiece housing (item 209) while pointing the stunner in a safe direction.
- 2. Grasp trigger housing (item 109) with the other hand and unscrew in a counterclockwise direction to reveal the cartridge breech (rear end of barrel where cartridge is loaded).



- ↑ 3. Ensure cartridge breech has no obstruction.
 - 4. Load appropriate cartridge for your application. Do not exceed maximum specified grain load for your stunner. Maximum permissable grain load is etched on the nosepiece housing (item 209).
 - 5. Keep stunner pointed in a safe direction and reassemble trigger housing (item 109) to nosepiece housing (209). Hand tighten securely.
 - 6. Arm stunner by pulling back on cocking cap (item 101) until it clicks into position.



- 7. To discharge stunner, use one hand to grasp stunner by knurled sections of nosepiece and trigger housings (items 209 and 109). Use other hand to fully depress trigger (item 107) with index finger to fire stunner.
 - 8. Remove spent cartridge by redoing steps 1-2.

MAINTENANCE INSTRUCTIONS



Read thoroughly the entire operator's manual before attempting to assemble or disassemble this stunner. Always treat the stunner as if it were loaded. Make sure there are no cartridges in the breech housing.

PRIOR TO USE OR DAILY:

Refer to cleaning tools supplied with stunner.

- 1. Clean stunning rod (item 206) and nosepiece housing (item 209) with user supplied gun powder solvent.
- 2. Wipe all metal surfaces with rag and gun oil.
- 3. Do not apply gun oil to bumpers (item 208) or bumper washers (item 207).
- 4. Examine bumpers (item 208), bumper washers (item 207) and nosepiece o-ring (item 203). Replace if worn.

DISASSEMBLY INSTRUCTIONS

Read thoroughly the entire manual before attempting to assemble or disassemble this stunner.

Always treat the stunner as if it were loaded. Make sure there are no cartridges in the breech block.

- 1. Unscrew nosepiece and breech housing assemblies (items 201-212) from trigger housing assembly (items 101-109).
- 2. Remove muzzle (item 212).
- 3. Unscrew breech (item 205) from nosepiece housing (item 209) and remove o-ring (item 203) from breech.
- 4. Using two wrenches, unscrew knocker head (item 211) from stunning rod (item 206).
- 5. Remove stunning rod (item 206), four bumpers (item 208) and two bumper washers (item 207) from nosepiece housing (item 209).
- 6. Unscrew cap (item 103) from trigger housing (item 109) while depressing trigger to remove firing pin assembly (items 101-105).
- 7. Remove trigger (item 107) and rubber insert (item108) from trigger housing (item 109).
- 8. Remove o-ring (item 106) from trigger housing (item 109).
- 9. Unscrew cocking cap (item 101) from end of firing pin (item 105).
- 10. Remove rubber spring (item 102) from cocking cap (item 101).
- 11. Remove firing pin (item 105) and firing pin spring (item 104).
- 12. Remove firing spring (item 104) from firing pin (item 105).

ASSEMBLY INSTRUCTIONS

- 1. Reverse steps 12 to 9. Tighten securely.
- 2. Grease o-ring (item 106) after installing onto trigger housing (item 109).
- 6. Reverse steps 7 to 2.
- 7. Screw nosepiece and breech housing assemblies (items 201-212) onto trigger housing assembly (items 101-109) and hand tighten securely.

TROUBLESHOOTING INSTRUCTIONS

STUNNER FAILS TO FIRE:

1. Make sure nosepiece and breech housing assemblies (items 201-212) are securely engaged with trigger housing assembly (items 101-109). Secure engagement is critical to the proper operation of this stunner and the prevention of cartridge misfires and rim failures.

Power Actuated Stunners (PAS) TYPE-C IMPACT FIRE Instructions

OPERATION INSTRUCTIONS

◬

Thoroughly read and understand all safety instructions and ensure that the tool is in proper working condition before at-tempting to use this stunner.

- Remove barrel assembly (items 101-109) from stunner cap assembly (items 110-118) by rotating the barrel assembly until the red dots are not aligned. Firmly pull barrel assembly from stunner cap assembly.
- 2. Ensure breech block (item 109) has no obstructions.



- Load appropriate cartridge for your application. Do not exceed maximum specified grain load for your stunner. Maximum permissible grain load is etched on the breech block (item 109).
- 4. Hold the barrel (item 107) upright. Slide the stunner cap assembly (items 110-118) over the barrel assembly (items 101-109) with the red dots on each assembly not aligned.
- Insert firmly until the brass balls (item 116) engage the detent in the barrel (item 107).



- 6. The stunner is now in the "safe" position (red dots not aligned).
- 7. Rotate the barrel assembly while holding the stunner cap assembly to align the red dots. The stunner is now in the "fire" position.
- 8. Firmly strike the muzzle end of the barrel against the intended target to discharge the stunner.
- Rotate the barrel assembly while holding the stunner cap assembly until the red dots are not aligned. The stunner is now in the "safe" position.



MAINTENANCE INSTRUCTIONS

Read thoroughly the entire operator's manual before attempting to assemble or disassemble this stunner.

Always treat the stunner as if it were loaded. Make sure there are no cartridges in the breech housing.

PRIOR TO USE OR DAILY:

Refer to cleaning tools supplied with stunner.

- Clean stunning rod (item 106) and barrel (item 107) using supplied cleaning tools and user supplied gun powder solvent.
- 2. Wipe all metal surfaces with rag and gun oil.
- 3. Do not apply gun oil to stunning rod bumpers (item 104) or stunning rod washers (items 102, 103 and 105).
- Examine stunning rod bumpers (item 104), red bumper washers (item 103), blue bumper washer (item 105) and nosepiece lock washer (item 102). Replace if worn.

DISASSEMBLY INSTRUCTIONS

Read thoroughly the entire manual before attempting to assemble or disassemble this stunner. Always treat the stunner as if it were loaded. Make sure there are no cartridges in the breech block.

- Remove barrel assembly (items 101-109) from stunner cap assembly (items 110-118) by rotating the barrel assembly until the red dots are not aligned. Firmly pull barrel assembly from stunner cap assembly.
- 2. Remove two o-rings (item 117) from stunner cap housing (item 111).
- 3. Remove three stunner claws (item 115) and three brass balls (item 116) from stunner cap housing (item 111).
- Unscrew firing pin (item 110) from stunner cap housing (item 111).
- 5. Unscrew muzzle (item 101) from barrel (item 107) using supplied spanner wrench.
- Remove stunning rod (item 106), stunner bumpers (item 104), red bumper washers (item 103) and blue bumper washer (item 105) from barrel (item 107).
- 7. If necessary, remove breech block (item 109) by unscrewing it from barrel (item 107). Remove and replace four thread locking plugs (item 108).

ASSEMBLY INSTRUCTIONS

- Insert three brass balls (item 116) into stunner cap housing (item 111).
- 2. Insert three stunner claws (item 115) into stunner cap housing (item 111).
- Install two O-rings (item 117) over stunner claws (item 115) and brass balls (item 116) to secure them in stunner cap housing (item 111).
- 4. Apply a medium strength thread locking compound to threads of firing pin (item 110) before installing firing pin into stunner cap housing (item 111).
- Insert four thread locking plugs into pockets on breech block (item 109).
- 6. Thread breech block (item 109) into barrel (item 107).
- 7. Install stunning rod (item 106), blue bumper washer (item 105), stunner bumpers (item 104) and red bumper washers (item 103) into barrel (item 107).
- 8. Install nosepiece lock washer (item 102) onto muzzle (item 101). Then screw muzzle into barrel (item 107). Tighten with supplied spanner wrench.



TROUBLESHOOTING INSTRUCTIONS

STUNNER FAILS TO FIRE:

- 1. Make sure red dots on the stunner claws (item 115) and barrel (item 107) are aligned.
- 2. Make sure breech block (item 109) and stunner cap housing (item 111) are free of debris or obstructions.
- 3. Make sure firing pin (item 110) is not worn or damaged.



USSS-1 Penetrating Pneumatic Stunner

Pneumatically operated high speed captive bolt stunner for cattle.



Item No. 3028 9405 **JARVIS NO. 4044005**

- Renders stunned animal insensible to pain.
- One shot humane stunning procedure. Fires only once — no multiple firing.
- Better stunning for improved meat quality.
- Air operated with no air injection.
- Easy to handle and safe to operate.
- · Low recoil or kick back.
- Easy to repair and clean.
- Lightweight tool only weighs 32.4 pounds (14.7 kg).

USE WITH KROMER™ BALANCERS. SEE PAGES 422-423 OF OUR BUYERS GUIDE OR VISIT WWW.PACKERSKROMER.COM






Two hand control for safer operation.

USSS-2A Non-Penetrating Pneumatic Stunner

Pneumatically operated high-speed, non-penetrating stunner for cattle and veal.







USSS-2 A Non-Penetrating Stunner with head type restrainer

USSS-2A

Item No. 3028 87171 JARVIS NO. 4044010

- Renders stunned animal insensible to pain.
- One shot humane stunning procedure. Fires only once — no multiple firing.
- Better stunning for improved meat quality.
- Air operated with no air injection.
- Two hand control for safer operation.
- Easy to handle and safe to operate.
- Low recoil or kick back.
- Lightweight tool only weighs 32.4 pounds (14.7 kg).
- Easy to repair and clean.

USE WITH KROMER™ BALANCERS. SEE PAGES 422-423 OF OUR BUYERS GUIDE OR VISIT WWW.PACKERSKROMER.COM



USSS-1/2 Size Penetrating Pneumatic Stunner



Item No. 3028 38021 **JARVIS NO. 4044042**

USSS-1/2

- Renders stunned animal insensible to pain.
- One shot humane stunning procedure. Fires only once — no multiple firing.
- Better stunning for improved meat quality.
- Air operated with no air injection.
- Dual handles with trigger control for easier handling and operation -- less operator fatigue.
- Low recoil or kick back.
- Easy to repair and clean.
- Lightweight tool only weighs 15.5 pounds (7.03 kg).

USE WITH KROMER™ BALANCERS. SEE PAGES 422-423 OF OUR BUYERS GUIDE OR VISIT WWW.PACKERSKROMER.COM

Pneumatic Stunner replacement parts available Call for details



Thoroughly read and understand all safety instructions and ensure that the stunner is in proper working condition before attempting to use this stunner.



Pneumatic Stunner Tester

For use with JARVIS pneumatic stunners.

- Fast, accurate tool for testing and calibrating Jarvis' pneumatic stunners.
- Safe and precise method for testing stunners.
- Durable construction ensures long service life.
- Economical and simple to operate.
- Lightweight, easy to assemble and store.

NOT for use with PAS - Power Actuated Stunners.



for use with USSS-1 Item No. **3028 1256** JARVIS NO. 4016004

• 115 Volt

AST-102

for use with USSS-2 Item No. **3028 60481** JARVIS NO. 4016007 • 115 Volt

Item No. **3028 60491** JARVIS NO. 4016008 • 230 Volt

AST-103

for use with USSS-2A Item No. **3028 87111** JARVIS NO. 4016009 • 115 Volt

Item No. **3028 60501** JARVIS NO. 4016010 • 230 Volt



AST-102 Pneumatic Stunner Tester



AST-101 Pneumatic Stunner Tester



KnockerVest[™] with Detachable Groin Protector

Designed for body protection while using stunning equipment.

- Made of Twaron® ballistics (wrapped in a water resistant package) that meet the highest standards for soft body armor.
- Back of vest is made of a tough, breathable open nylon mesh that is made to withstand multiple washings.
- Groin protector and cover are both sold separately.
- The ballistics are backed with 1/2" closed-cell foam and inserted in a 1,000 denier Cordura carrier vest coated with a urethane film for even more water resistance.
- Adjustable shoulder straps ensure a great fit.

KnockerVest™ is a trademark of JHRG Manufacturing LLC.



BREATHABLE NYLON MESH BACK



EASILY DETACHABLE **GROIN BALLISTICS PROTECTION**



CHEST BALLISTICS PROTECTION IS EASILY REMOVED TO **CLEAN VEST**

- KnockerVest, Size: Large/22" Item No. 4009 0102
- KnockerVest, Size: X-Large/24" Item No. 4009 0103
- Groin Protector Pad w/ 3-snap attachment Item No. 4009 0104
- Groin Protector Cover, color: black Item No. 4009 0010

TO USE EYE & EAR PROTECTION

3M™ OX™ 2000 Safety Glasses

specifications carefully before use.

Fits over most prescription lenses.

• DXTM anti-fog hard coat protects lens from fog, scratching, and most chemicals.

Adjustable length Secure Grip[™] temple fits virtually any size face.

· Lightweight, seamless lens with built-in side shields.

• Meets the requirements of ANSI Z87.1-2003 and CSA Z94.3-2007.

• Black frame, clear lens.

Item No. 3207 21661

OM24+® Earmuffs

• Ultra lightweight design.

 Multiple-position headband: over the head, behind the head or under the chin







Item No. 3140 46201

Complete JARVIS® Cleaning Tool Kit



Cleaning Tool Kit Item No. 3028 36241 JARVIS NO. 3161006

Includes 1-each of tools #1-11 shown

- Hexagon Wrench
- Push Rod
- Pick
- Undercut Cleaner
- Spanner (Wrench)
- 16 mm Cone Wrench
- 14 mm Cone Wrench
- Breech Cleaner Assembly
- Manual Extractor
- Hand Brush
- Tool Roll



CLEANING TOOLS

Everything you need to help keep your stunner performing at its optimum.



| ITEM NO. | JARVIS NO. | # | DESCRIPTION |
|------------------|------------|----|-----------------------------|
| 3028 36901 | 8139147 | 01 | HEXAGON WRENCH |
| 3028 78251 | 8133013 | 02 | PUSH ROD |
| 3028 36261 | 8137019 | 03 | PICK |
| 3028 77681 | 8137018 | 04 | UNDERCUT CLEANER/SCRAPER |
| 3028 78391 | 8130074 | 05 | SPANNER (WRENCH) |
| 3028 78231 | 8130076 | 06 | 16 MM CONE WRENCH |
| 3028 78221 | 8130075 | 07 | 14 MM CONE WRENCH |
| 3028 77751 | 8137017 | 80 | BREECH CLEANER |
| 3028 36271 | 8132003 | 09 | MANUAL EXTRACTOR/PRY BAR |
| 3028 36311 | 8137020 | 10 | WIRE HAND BRUSH |
| 3028 36331 | 1171638 | 11 | ROLL-UP TOOL POUCH |
| Call for details | 1171629 | 12 | STEEL CLEANING BRUSH, SMALL |
| 3028 77881 | 1171627 | 13 | STEEL CLEANING BRUSH, LARGE |
| 3028 77831 | 1119309 | 14 | STEEL BRUSH HANDLE |
| 3028 77631 | 1171012 | 15 | BRASS CLEANING BRUSH |
| 3028 38001 | 1171013 | 16 | COTTON CLEANING BRUSH |
| 3028 38011 | 1119002 | 17 | BRASS BRUSH HANDLE |
| 3028 77861 | 1162047 | 18 | ANTI-SEIZE GREASE, 4-OZ. |







800-456-5624

G96 Gun Oil Stunner Cleaning Solvent

We highly recommend using G96 when cleaning your stunner!

• 16-oz.

Item No. 3028 78211

• 12-oz.

Item No. 3948 0096

DuraPro® XCP Boot

- Sloped comfort top rim prevents chafing and reduces discomfort when walking, bending and kneeling.
- Larger circumference at the top makes it quick and easy to pull the boot on.
- Inner liner allows for increased flexibility and subtle feel at the calf.
- Conformance information molded in sidewall for easy identification.
- Wider metatarsal design and comfort ankle for all day comfort.
- DuraPro® insoles provide superior shock absorption, support and comfort.
- Honeycomb design molded inside the heel to reduce impact when walking.
- Ergonomically designed foot-bed to provide better underfoot support.




Plain Toe available. Call for details or order online www.bunzlpd.com

Brown DuraPro® XCP Superpoly Upper

For use in the red meat industry where high chemical resistance is required.







Safety-Loc Sole.


Blue DuraPro® XCP Polyblend Upper

For use in the poultry industry where moderate chemical resistance is required.





Foot Protector for Shoes WITH laces Item No. 5140 2101



Foot Protector for Shoes WITHOUT laces Item No. 5140 0107

Stainless Steel Foot Protectors

- For best protection, the guard should be positioned so that it rests upon the steel toe of shoe or boot.
- Stainless steel shell with aluminum rivets.
- For use on Mens' shoes/boots sizes 6-13. Sold per pair.



F.O.B. FACTORY



INSULATED CLOTHING, FROCKS & LINERS available in our Buvers Guide Catalog or order on our website:

www.bunzlpd.com



NorthFlex Cold Grip™ Gloves

Foamed PVC palm-coated, lined gloves

• Recommended for temperatures down to -15° F (-26° C).

Honeywell Seamless brushed synthetic liner provides NORTH superior insulation from the cold.



3476 86351 Size 8/Medium 3476 86361 Size 9/Large **3476 86371** Size 10/X-Large 3476 86381 Size 11/2X-Large

More Gloves & Safety Products available in our **Buyers Guide Catalog** CALL TO REQUEST YOUR FREE COPY or order on our website: www.bunzlpd.com





Includes Staz-On suspension



Optional Ratchet-style replacement suspension

V-GARD® Safety Hard Hat

Lightweight and comfortable to wear all day.

- Injection molded of non-conductive high-density polyethylene.
- Meets requirements for Type 1, ANSI/ISEA Z98.1-2009 (Class E) and CSA Z94.1-2005 (Class E)
- Provides a minimum safety crown clearance of 1-1/4" between top of head and shell.
- Choose from 13 colors.



| ITEM NO. | COLOR |
|------------|--------|
| 3085 71271 | White |
| 3085 71291 | Green |
| 3085 71281 | Blue |
| 3085 71301 | Yellow |
| 3085 71311 | Red |
| 3085 71321 | Orange |
| 2005 71221 | Grav |



3085 71331 Grav 3085 48511 Gold 3085 11801 Tan 3085 31111 Light Blue **3085 11241** Burgundy 3085 53641 Pink

3085 52301 Hot Pink (ratchet style)

3085 79211 Replacement Staz-On Suspension 3085 87081 Replacement Ratchet Suspension

Nitrile Disposable Gloves

• Fingertip texture improves grip without sacrificing dexterity.

2016-2017

• 9" glove length. • Ambidextrous. • More colors & styles available, Call for details.

350 SERIES ECONOMY

• 2.5 mil. at the palm.



➤ 100 per box — 10 boxes per case.

ITEM NO. SIZE E542 02175 Small E542 02195 Medium E542 02155 Large E542 02165 X-Large E542 32205 2X-Large



450 SERIES INDUSTRIA

• 3.5 mil. at the palm.

Powder-Free

➤ 100 per box — 10 boxes per case

ITEM NO. SIZE 7500 86295 Small 7500 86395 Medium 7500 86495 Large 7500 86595 X-Large 7500 86695 2X-Large





WE HAVE SO MUCH MORE TO OFFER

This stunner catalog showcases our humane stunning supplies and equipment, but we have so much more to offer. Our inventory includes over 35,000 ready-to-ship items from 14 distribution centers serving Central and North America, including the Caribbean and Mexico!

Additional supplies and equipment available in our Buyers Guide catalog.

Call to request your FREE copy!

800-456-5624

Or, visit us online



También ofrecemos asistencia al cliente en español. Llame al 800-746-7990 para comunicarse con uno de nuestros representantes bilingües.

CUSTOMER SERVICE FROM PEOPLE WHO CARE

Bunzl Processor Division establishes close relationships

with our vendors, and because of this our customer service representatives are experts on all the products that we sell—giving them a professional working knowledge of how these products best serve the food processing industry.

Whether you have a rush order or need to arrange regular shipments, you can count on us for the friendliest, most dependable service. Our experienced staff will answer your questions on pricing, product availability and any other technical questions you may have, as well as take your order.



WE OFFER THE INVENTORY AND PARTS THAT YOU NEED — WHEN YOU NEED THEM

We offer product categories such as clothing, jan/san, material handling, plant remodeling, safety, cutlery, scales, thermometers, processing supplies, seasonings, packaging and maintenance, repair and operation supplies (MRO). Our inventory includes over 35,000 ready-to-ship items, so you don't have to wait long to receive the supplies you need. We are committed to getting your order shipped to you fast and complete — it's that simple.

Shop our website 24/7! It's the best way to always find current pricing.



Ready to shop? www.bunzlpd.com

will take you directly to our website.
The easy-to-navigate category links show all the products that are available on our website. From clothing to cleaning products and from cutlery to packaging supplies, you will find everything at your fingertips.

BUNZL PROCESSOR DIVISION DISTRIBUTION CENTERS

Our inventory includes over 35,000 ready-to-ship products from 14 distribution centers serving Central and North America, including the Caribbean and Mexico.



Springdale, AR Fresno, CA Frederick, CO Atlanta, GA Eldridge, IA Liberal, KS Austin, MN North Kansas City, MO St. Pauls, NC Omaha, NE Fairfield, OH York, PA Dallas, TX Spokane, WA

WWW.BUNZLPD.COM

Stay connected with us:

















528 East 19th Avenue North Kansas City, MO 64116 800-456-5624



Scan this QR code with your mobile device for a direct link to our website.